




## Perry Propeller Nut Anode Installation Instructions

- Make sure your boat anodes have proper physical and electrical connections.
- An anode with a poor electrical connection cannot provide corrosion protection.
- Clean the area where your anodes will be mounted by lightly sanding or wire brushing.
- Do not paint your anodes.

(INSPECT PARTS BEFORE INSTALLING)

STEP 1. INSTALL PLAIN HEX NUT INTO HEX SIDE OF ZINC. NUT MUST BOTTOM ON BRASS WASHER AND BE AT LEAST 1/32" ABOVE ZINC, AS SHOWN IN SKETCH BELOW.



STEP 2. REMOVE NUT FROM ZINC, INSTALL NUT ON SHAFT AND TIGHTEN WITH WRENCH.

STEP 3. INSTALL ZINC WITH HEX SIDE OVER NUT.

STEP 4. INSTALL CASTELLATED NUT AND TIGHTEN WITH SOCKET WRENCH.

STEP 5. INSTALL COTTER PIN.

STEP 6. WHEN INSTALLATION IS COMPLETED, INSPECT TO MAKE SURE THAT ZINC DOES NOT BOTTOM ON PROP. YOU MUST BE ABLE TO SEE FIRST NUT THAT WAS INSTALLED.

